### DIGITAL RECIRCULATION VALVE

Engineered exclusively for continuously recirculated hot water systems, DRV50 improves system performance and safety by delivering a consistent preset temperature to the points of use.

Innovative digital technology resists "temperature creep" during periods of zero system demand which eliminates the requirement for manual throttling valves, supplementary RTD or a temperature actuated switch to control the pump.

Energy efficient, low temperature loss systems can be implemented by the ability of DRV50 to operate with a system return differential of just 1° F below set point.

User safety and overall system health is maintained by a series of programmable temperature alerts, onboard operational self-diagnostics, and a thermal disinfection option.



The Brain® Model DRV50

DRV50 Performance Chart: Pressure Drop (in PSIG) to Flow Rate (in GPM)							
DRV50	Pressure Drop (PSIG)				Minimum System	Minimum Flow Rate	C
	5	10	15	20	Draw-Off	Willillium Flow hate	V
GPM	94	133	163	188	0 GPM	10 GPM	42

DRV50 Performance Chart: Pressure Drop (in BARG) to Flow Rate (in LPM)							
DRV50	Pressure Drop (BARG)				Minimum System	Minimum Flow Rate	V
	0.3	0.7	1.0	1.4	Draw-Off	Willilliulli Flow hale	N <sub>V</sub>
LPM	355.8	503.5	617	711.1	0 LPM	38 LPM	36.33

Designs, materials, weights, and performance ratings are approximate and subject to change without notice. Visit armstronginternational.com for the most up-to-date information.



# **TECHNICAL SPECIFICATIONS**

General						
Protection	NEMA 3S, IPX4					
Ambient Temperature	'					
Ambient Humidity	Minimum Ambient Temperature: 35°F (2°C)  Maximum Ambient Temperature: 122°F (50°C)					
,	95% Non-Condensing					
Installation Environment	Suitable for indoor use only					
Materials	Valve: Stainless Steel, Electronics Module: PC / ABS  Seven fail-safe cold triggers supported by integral self-diagnostics and a programmable over-temp limit					
Safety	Seven fail-safe cold triggers supported by integral se	en-diagnostics and a programmable over-temp limit				
Connections	2" NDT Female Connections					
Inlet and Outlet Connections	2" NPT Female Connections					
Pressures	Marine & Breeze & 200 and /4270 LDA 42.0 km	Mining at Days on 20 and 420 LDA - 4.5 has				
Inlet Supply Pressures	Maximum Pressure: 200 psi / 1379 kPA = 13.8 bar Minimum Pressure: 20 psi / 138 kPA = 1.5 bar					
Supply Pressure Differential	Nominally equal					
Temperatures						
Hot Water Supply Temperature	Maximum Inlet Hot Supply Temperature: 185°F (85°C)	Minimum Inlet Hot Supply Temperature: 5°F (2°C) above DRV set point				
Cold Water Supply Temperature	Minimum Inlet Cold Supply Temperature: 35.6°F (2°C)					
Min. Recirculation Temperature Loss	1°F ( ≤ 1°C)					
Min. Continuous Recirculation Flow	10 GPM (38 LPM)					
Recirculation Circuit						
Minimum Distance to First Outlet	25 ft (7.6 m)					
Electrical						
Power Supply	120 - 240V AC - 50/60 Hz					
Supply Fuse / Circuit Breaker	Grounding required (Switched Type 3 Amp - no plug; 15 Amp Grounding-type receptacle - plug)					
Battery	Qty (2) CR - P2 6V					
Configurable Settings						
Set Point Range	81°F to 158°F (27°C to 70°C)					
High Temperature Alert	Minimum of 2°F (1°C) above DRV set point					
High Temperature Error	5°F (2°C) above DRV set point					
Thermal Disinfection Temperature	Programmable range of 158°F to 185°F (70°C to 85°C)					
Thermal Disinfection Set-Up	Disinfection Duration: ≤ 100 minutes	Disinfection Cool Down Duration: ≤ 30 hours				
Units of Measure	Degrees Fahrenheit (°F) or Degrees Celsius (°C)					
Connectivity						
Bluetooth®	On board with SAGE® mobile application (available in the Apple App Store and Google Play)					
BACnet MSTP	On board for connection to building automation system (BAS) operating on BACnet MSTP protocol					
Modbus RTU	RS-485 port for connection to building automation systems (BAS) operating on Modbus RTU protocol					
SAGE® Module	RS-485 port for connection to SAGE® module with Modbus TCP, BACnet TCP/IP, BACnet MSTP, or LonWorks protocessor  Note: Protocessors for other BAS protocols may be available upon request					
SAGE® Subscription	Real-time monitoring, recording, and documentation dashboard for Armstrong Hot Water Systems					
Standards and Approvals						
ASSE 1017	Certified & Listed					
CSA B125.3-11	Compliant					
UL	Listed					
CE	Listed					
	1					

Designs, materials, weights, and performance ratings are approximate and subject to change without notice. Visit armstronginternational.com for the most up-to-date information.



#### WRITTEN SPECIFICATIONS

Category: The Brain®

Type: Digital Recirculation Valve

Model: Model DRV50

Part 1 - GENERAL

### 1.0 Digital Recirculation Valve

- 1.1 DRV shall have four thermistors integral of the mixing valve body that measure the cold water and recirculation return inlet, hot water inlet, mixed water outlet, and over-temp safety measures.
- 1.2 DRV mixing valve body shall be of 316L stainless steel, mixing valve proportioner of 316L stainless steel, and a NEMA 3S electronics enclosure.
- 1.3 DRV50 shall have 2" inlet and outlet connections that will deliver 133 gpm @ 10 psid.
- 1.4 DRV shall be capable of +/-2°F control during high, low, or extended periods of zero demand on the system, with a continuous recirculation of >10 gpm. Temperature control shall be achieved without aquastat-like control of the recirculation pump.
- 1.5 DRV setpoint shall be configured by the factory to customer specification. DRV shall be field adjustable.

### 2.0 DRV50 shall have the following operational specifications:

- 2.1 +/-2°F (1°C) water temperature control
- 2.2 1°F minimum mixed water outlet to recirculated return inlet differential (system temperature loss)
- 2.3 Minimum continuous recirculation of 10 gpm
- 2.4 Automatic shutoff of hot water upon cold water inlet supply failure
- 2.5 Automatic shutoff of hot water flow in the event of a power failure
- 2.6 Programmable setpoint range of 81°F 158°F (27°C 70°C)
- 2.7 Programmable thermal disinfection mode
- 2.8 Programmable 1st level hi/lo temperature alert display
- 2.9 Programmable temperature error level for safety shutdown

## 3.0 DRV50 shall have the following connectivity specifications:

- 3.1 Bluetooth® on-board with SAGE® mobile application (Apple App Store and Google Play)
- 3.2 BACnet MSTP on-board for connection to building automation system (BAS) operating on BACnet MSTP protocol
- 3.3 Modbus RS-485 port for connection to building automation system (BAS) operating on Modbus RTU protocol
- 3.4 RS-485 port for connection to SAGE® module with Modbus TCP, BACnet TCP/IP, BACnet MSTP, or LonWorks protocessor
  - Note: Protocessors for other BAS protocols available upon request

#### 4.0 DRV shall be certified to ASSE 1017, UL listed, and conform to CSA B125.

#### 5.0 Warranty

- 5.1 DRV shall have a 5-year warranty on all components, with the exception of batteries and O-rings.
- 5.2 Pre-piped DMC components shall have a 2-year warranty from date of installation, but not longer than 27 months from date of shipment.





#### CONNECTIVITY



## The Brain® and SAGE®

SAGE® works seamlessly with The Brain® as it analyzes data to track behavior and performance as an integral component of a hot water system operation protocol which complies with a standard of care.

The Brain® and every derivative assembly is supplied with an integral RS-485 serial port. This port provides a direct connection to Building Automation Systems that operate on a **Modbus RTU** or **BACnet MSTP** protocol.

The RS-485 port is also deployed for direct connection to an optionally supplied Building System (BS) Module.

# **SAGE®** Options

SAGE® for Building Automation Systems (BAS) — BS Module available with BAS specific ProtoCessor cards for connection to systems which operate on Modbus TCP, BACnet™ TCP/IP, BACnet™ MSTP, or LonWorks™ protocols

**SAGE®** for Mobile Connectivity - Featuring smart hot water system dashboard monitoring, secure remote programming, multi-location view, temperature and system diagnostic alerts, with unlimited digital documentation and automated report generation.

Mobile connectivity may be enabled by a customer activated no-term subscription.



# **Optional Building System (BS) Module**

Adding a suffix "BS" to The Brain® DRV (example: DRV25<u>BS)</u> will automatically add SAGE®, the supplemental hardware and software required to maximize the connectivity features of Armstrong digital technology.

Designs, materials, weights, and performance ratings are approximate and subject to change without notice. Visit armstronginternational.com for the most up-to-date information.





