



Armstrong Hot Water Group

221 Armstrong Blvd., Three Rivers, Michigan 49093 – U.S.A. Phone: (269) 279-3602 Ž Fax: (269) 279-3130

Accessing BrainScan via Ethernet

NOTE: This is assuming that BrainScan's IP address has not been changed from factory defaults since leaving the Armstrong Factory.

Items needed:


Ethernet Cable

Computer with Admin access

Windows 7

Click Start -> Control Panel -> Network and Sharing Center

Click "Change adapter settings" on the left side of the window




Intelligent System Solutions STEAM Ž AIR Ž HOT WATER

www.armstronginternational.com




Right-click your network adapter and then click Properties





Select Internet Protocol Version 4 (TCP/IPv4) then click Properties





Select “Use the following IP address” and fill out the form as shown.

Click OK and exit both the TCP/IPv4 window as well as the Local Area Connection window.

Open your web-browser and access the following address

<https://172.16.31.201>

Default username is :armstrong

Default password is: brainscan

If there are only 5 brains on the left hand side and there is no admin configuration page and you need to change the date/time or change processor settings, access the following address using a web-browser

<https://172.16.31.201/admin/config.php>

Username: ahwgdvr80

Password: choffma

